

THE KIT BAG

Alice Pack Assembly Instructions



To assemble, you will need...



One Alice Frame



One Alice Pack



One Set of Alice Enhanced
Shoulder Straps



One Alice Enhanced
Kidney Waist Belt

Unit 7, 14 Farrall Road, Midvale, Perth, WA 6056

Tel: 61 8 9250 8448

Fax: 61 8 9250 8449

Email : info@kitbag.com.au

www.kitbag.com.au

Green Harbour Pty Ltd T/As KITBAG A.B.N 89 791 318 455

Start with one Alice Frame.



Place the Kidney Belt next to the frame, remove both Fastex clips (as shown).

Feed the webbing through the steel loops of the Alice frame. Reattach the Fastex clips.





Ensure that both the large and small webbing go through the steel Alice frame loops

Clip the Fastex clips together and tighten.



Slide the top of the Alice frame into the rear top pocket of the Alice pack.

Feed the 2 Fastex clips attached to the bottom of the Alice pack through the small hole at the bottom of the Alice frame.



Clip these together & tighten. This will secure the pack to the frame.

Disconnect the bottom clip/webbing loops from the bottom of the Alice Shoulder straps.





Feed this clip & webbing through the large hole at the bottom of the Alice frame.

Feed the clip through its own loop at the end and tighten.



Feed the webbing from the top of the shoulder strap through the top of the Alice pack and feed it around the Alice frame (as shown).

Top view of the Alice pack showing where both straps are feeding through the top hole and around the frame.



Inside View, both shoulder straps are fed the same way.

Feed the webbing through the Fastex ladderlocks on the top of the shoulder straps.



Congratulations on the assembly of your Alice Pack. Please adjust all straps and clips to suit the user.



Any problems please contact us on 08 9250 8448